


WHAT ELSE DO YOU NEED?

- 12 batteries, type LR6 (AA) 1.5V or equivalent NiMH chargeable batteries
- Smartphone or tablet
- A stable data connection (for app download)

12x



DO YOU HAVE ANY QUESTIONS?

For answers to frequently asked questions go to:

www.minox.com/app-dtc1200

Here, you will also find all instruction manuals, support information and additional contact options should you require detailed help.



MINOX GmbH

Walter-Zapp-Str. 4 · 35578 Wetzlar · Germany

Phone +49 (0) 64 41 / 917-0 · Fax +49 (0) 64 41 / 917-612

info@minox.com · www.minox.com

QSG DTC 1200, EN, 10/2019

MINOX

QUICK START GUIDE

DTC 1200

TRAIL CAMERA



IS EVERYTHING INCLUDED?

- 1 | MINOX DTC 1200 trail camera
- 2 | 4G radio antenna
- 3 | Fastening strap
- 4 | 16 GB microSD card with adapter
- 5 | Quick Start Guide
- 6 | Safety instructions

WHAT IS WHAT?

- 1 | Antenna connection
- 2 | Operating mode switch
- 3 | SD card slot
- 4 | Battery compartment release
- 5 | Video monitor



LET'S GET STARTED

- 1 | Scan the QR code or go to www.minox.com/app-dtc1200 to install the app
- 2 | In the app:
 - a | Set up the user profile.
 - b | Scan the QR code in the camera (sticker).
 - c | Activate mobile data transfer (if desired).
 - d | Configure the camera.
- 3 | Attach the antenna.
- 4 | Insert the batteries.
- 5 | Insert the SD card.
- 6 | Switch the camera to Setup Mode and wait for the settings to be transferred from the app to the camera.
- 7 | Mount and align the camera at the desired location.
- 8 | Set the power switch to ON.
- 9 | Close the camera cover.
- 10 | Now you can view the sent images in your MINOX Cloud via the app. You can also remove the SD card to save the images directly onto your computer.

